

## Peracetic Acid (PAA) Test Paper 0-160ppm



Measure Peracetic Acid in solutions fast and accurate using the PAA test strips.

Rating: Not Rated Yet

**Price**


[Ask a question about this product](#)

### Description

The Hydrion Peracetic Acid test strips provides producers a convenient and reliable means to measure PAA within the range of 0 - 160ppm. Results are available within seconds.

### Instructions:

1. Immerse test strips for no more than 1-2 seconds in test solution.
2. Remove the test strip from solution and immediately shake to remove excess solution.
3. Match at 10 seconds (no more than 15 seconds) to colour chart for accurate PAA measurement.



### Ordering Details:

Product Code: PAA - 160

Number of Strips per Vial: 50

### Storage:

Room Temperature