

## Total Chlorine Test Papers 10 to 200ppm



Total Chlorine Test Papers to verify sanitiser level within seconds.

Rating: Not Rated Yet

Price

[Ask a question about this product](#)

### Description

LaMotte Total Chlorine Test Papers for Total Chlorine offer a user friendly means to verify sanitiser levels in waters. The test strips are supplied packed in a container with easy to follow instructions and colour guide to interpret results. The added benefit of the test strips is that reagents or field kits are not required.

### Specifications:

Range: 0, 50, 100, 200ppm

### Instructions:

1. Immerse one inch of test strip in solution.
2. Remove immediately. Blot strip once on a paper towel to stabilize colour.
3. Compare strip to colour chart.

### Ordering Details:

Pack of 100

Product Code: 4250-BJ-100



