

Hydrion® Free Available Chlorine Test Strips 10 - 200ppm



Measure with ease the amount of free available chlorine in sanitising solutions.

Rating: Not Rated Yet

Price

[Ask a question about this product](#)

Description

Hydrion® Chlorine Test Paper provides a simple, reliable, and economical means to measure the concentration of free available chlorine in sanitising solutions. The test paper measures between 10-200ppm with colour matches at 10-50-100-200.



1. Dip test strip into solutions and remove.
2. Blot dry with paper towel.
3. Read immediately by comparing the colour on the strip to the colour grid on the side of the bottle.

Storage Conditions:

Away from sunlight at room temperature.

Ordering Details:

Product Code: CM-240V

200 strips per bottle

